# ZEN FF VISOR CE



WVI00008



Polycarbonate face protection designed to work with all Zenith series helmets. EN 166 rated to protect the eyes of workers from medium level energy impacts. Available in 2 lens color options for various levels of light transmission. Securely lips up and down. Attaches with Easy Click Visor Adaptors and ZEN Face Shield Carrier.

## **TECHNICAL DETAILS**



**MATERIAL** 

Polycarbonate



**STANDARD** 

EN 166 / ANSI Z87.1 EN170 (clear) EN172 (smoke, silver mirror)



**OPTICAL CLASS** 



**TEMPERATURE OF USE** 

-5°C/+55°C



WEIGHT



**CATEGORY** 

### **TECHNOLOGIES**



Equipped with an anti-fog treatment to increase wearer visibility when active and in a variety of conditions.

Designed with a rubber upper contour to keep out sweat moisture



#### **PANORAMIC LENS**

Wide view lens for optimal protection and visibility.



#### SCRATCH RESISTANT

Equipped with a scratch-resistant treatment for increased durability.



#### **COMPATIBLE WITH GLASSES**

Designed for use over corrective glasses.



#### CUT PROOF FDGE

and to enhance comfort.

**DRIP PROOF UPPER CONTOUR** 

Designed with a cut proof edge for enhanced comfort and safety.



#### **EASY CLICK VISOR ADAPTERS**

Attaches visors or face shields to helmet.

#### **MARKINGS**

CODE	COLOR	MARKING
WVI00008-500	CLEAR	ZEN FF   20/04   <b>( (</b>   2C-1,2   <b>K//K</b>   1   BT   3   9   N
WVI00008-510	SMOKE	ZEN FF   20/04   <b>( €</b>   5-2,5   <b>K//K</b>   1   BT   3   9   N

#### ADDITIONAL INFORMATION

#### **GUARANTEE**

3 years starting from the date of purchase.

## YEARS YEARS SHELF LIFE

10 years starting from the date of manufacture. Shelf life depends on various factors that can cause deterioration such as sudden temperature changes, the amount of exposure to direct sunlight and the intensity of use.

Altered vision and scratches are elements that signal the need to check for deterioration of the visor.

Clean only with water and mild soap. Allow to air dry. Do not use chemical detergents, solvents, petrol powders as they are too aggressive and could lower the structural resistance of the visor. Do not rub the lens when dry.

## ZEN FF VISOR COLLECTION



ZEN FF VISOR CLEAR

WVI00008-510





KIT ZEN FF VISOR CLEAR



ADAPTERS





WAC00010

WKI00009 ZEN MOUNT KIT

**DISCOVER MORE** 





**SCAN FOR COMPLETE** COLLECTION









ZEN VISOR SMOKE